




# Dell Inspiron 7568 Cooling Fan Replacement Guide

This guide will show you how to replace the fan on your Dell Inspiron 7568.

Written By: Yash Samant



## INTRODUCTION

By following the steps in this guide one should be able to replace the fan on the device (Dell Inspiron 7568).


---



### TOOLS:



- Philips Head Screwdriver: Size PH1 (1)
-

## Step 1 — Battery



- Unscrew & remove the ten 7mm screws (using a ph1 screwdriver) holding the bottom cover
- Remove the bottom cover



## Step 2



- Unscrew & remove the four 3mm screws (using the ph1 screwdriver bit) holding the battery
- Unhinge the connector cable to the battttery
- Remove the battery





## Step 3 — Cooling Fan



- Unclip the cable connecting the fan to the mother board.
- Separate the motherboard cable from the clamp at the bottom of the fan.
- Remove the cable.

## Step 4



- Unscrew the two 3mm screws (using the ph1 screwdriver bit) holding the fan.
- Remove the fan

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-29 06:02:30 PM.